


LIBRARY OF THINGS

AGES
12+



SMARTPHONE GIMBAL

INSTRUCTIONS

For more information
and instructions,
please scan QR code. ↓



Hobsons Bay
COUNCIL+

Hobsons Bay
LIBRARIES

**HOBSONS
BAY CITY
COUNCIL**



SMARTPHONE GIMBAL

WHAT'S IN THIS KIT?

- 1 x Gimbal
- 1 x Tripod
- 1 x Magnetic Phone Clamp
- 1 x USB power cable

BEFORE RETURNING

Please ensure it is returned in good condition with all items accounted for.



1 x Gimbal



1 x Magnetic phone clamp



1 x Tripod




1 x USB power cable

This item **MUST BE** returned to the library desk during branch opening hours.

DO NOT RETURN VIA THE RETURN CHUTE

STEAM TECHNOLOGIES



WHAT YOU NEED:

DJ Mimo App (optional)

HOW TO USE:

1. Unfold Gimbal, it will power on once unfolded
2. (If you want to use the Tripod) Screw on Grip Tripod to the bottom of the Gimbal
3. Attach Magnetic Phone clamp to the centre of your phone (ensure that the arrow on the side of the clamp faces the direction of the camera)
4. Attach the clamp to the metal dot on the gimbal to start using (make sure the dots line up)
5. Press the on button ("M") to stabilize the gimbal
6. Use the joystick to control the movement of the gimbal direction

TROUBLESHOOTING AND SUPPORT

There is an excellent collection of support documents and videos here



We'd love to see your stories!
Tag us on Instagram and Facebook



#libraryofthings

STEAM TECHNOLOGIES

